



Page | 3 Eng-Custom© all rights reserved



PAY ATTENTION:

- When using the interface it is necessary that the original car radio is in AUX source
- o To mirrorlink on Android phones you need to enable "developer options and USB debugging"
- On your phone must be dissociated UCONNECT and connected to the interface.

Technical Assistance:

Mail:

assistenza@eng-custom.com

Phone and Whatsapp:

(+39) 347 36 57 843

Page | 4 Eng-Custom© all rights reserved